


PHE L110X100SPACER



Size	110
Distance between shaft ends	100
Distance between shaft ends (in)	3.94