


PHE L100X140SPACER



Size	100
Distance between shaft ends	140
Distance between shaft ends (in)	5.51